



HOW TO TRANSPORT YOUR CHAFING DISH



NO



YES

PROPER CARE: Like any fine product Bon Chef Chafing Dishes must be treated like the fine product they are. Bon Chef Chafing Dishes should be wiped clean after every use with a soft cloth. When needed a stainless steel polish may be used. Bon Chef Silver Chafers must be wiped with a soft cloth and when needed polished with silver polish. In the unlikely event the slowdown mechanism should fail replacement mechanisms are available and easily replaced by removing two screws.

TRANSPORTING: Bon Chef Chafers must be carried in their upright standing position by grasping each side of the frame with both hands. Bon Chef Chafing Dishes CANNOT be carried by one end of the frame only. To do so will dislodge the cover from the slow down mechanism. Bon Chef Chafing Dishes CANNOT be carried by the cover handle. Severe damage will occur when transported improperly.

In the event the cover has dislodged itself due to improper transportation follow these simple steps.- Remove the Cover - Stand the chafers on all four legs with the handle facing you - Take an open end wrench and turn each square axle toward you until it can't go any further - DO NOT EXERT EXTREME FORCE - The axle should be in the correct sequence of rotation. If the axles are not in the proper rotation sequence you will not be able to open the cover fully or perhaps not at all. Replace cover and now your chafing dish is good to go.